

Quick User Guide for Time Guard 7- Day event timer.



Setting/Changing the Day.

- Press the **Program** button once. The display flashes and shows the clock symbol.
- Press the **Change** button. The Icon representing the day starts to flash.
- Press the **Change** button to select the Day – 1 = Monday, 2 = Tuesday and so-on. When the selected day is set, press and hold the Program button until the current Time is shown.

Setting/Changing the Time.

- Press the **Program** button. The display flashes as above.
- Press the **Change** button. The “Day” Icon flashes as above.
- Press the **Program** button to select “Hours” (Hours starts to flash).
- Press **Change** to alter the hours or **Program** to move to the “Minutes” setting
- Press **Change** to alter the Minutes.
- When complete press & hold the **Program** button in until the current time is displayed.

Setting-up or Altering Timer schedules.

- Press the **Program** button twice to display the first “ON” time. (The display will flash)
- Press **Change** the days of the week now flash.
- Press **Change** to select the required day, week-day, weekend or entire week. Or...
- Press **Program** to move to the hours setting.
- Press **Change** until the required hour is displayed. Or...
- Press **Program** to move to the minutes setting
- Press **Change** until the required minute setting is displayed. Or...
- Press **Program** to move to the “OFF” setting.
- Press **Change** until the required hour is displayed. Or...
- Press **Program** to move to the minutes setting.
- Press **Change** until the required minute setting is displayed.
- At this point, if no other settings are required, press & hold the **Program** button until the time is displayed; otherwise use the **Program** button sequentially to advance through to the other “On” & “OFF” times. There are 6 all together.

It is advised to “VOID” all on/off time slots if not being used. To do this follow the steps above until you get to the unused slots. Advance through the Hours and Minutes as above until you see “--:--” in the display. (This is immediately after 23hr &/or 59min) The program should automatically set the OFF time in the same way but if it does not (earlier versions) manually enter the same value.

If at any point you think you have made an error, press and hold the **Program** button until the Time is displayed and start again.

To operate the timer as a “Manual Override” simply slide the ON, OFF, TIMER switch into the required position. **NOTE:** This mode is continuous and if left in the ON position, the gate/s will be kept open/unlocked until the switch is returned to the TIMER position.

To operate the timer in “Temporary Override” mode simply press the **CHANGE** button. If the timer is OFF, (see display for status) it will turn ON until the next OFF time is reached and vice-versa. This mode is more secure than Manual Mode.

To completely reset the timer back to factory settings press and hold the **CHANGE & PROGRAM** Buttons together. Release when the display disappears. **NOTE:** This will reset all previously stored times; therefore the timer will no longer operate your system.