Elgon Security Systems

3, Worcester Court
Saxon Business Park, Hanbury Road
Bromsgrove, Worcestershire. B60 4AD
Tel: 01527 570962 Fax: 01527 558979 info@elgonsecurity.co.uk

VX800-2N Short-Cut Programming Guide for 2 Door control

Step 1	Enter the MASTER Code: "111111" then press Enter. **The Red light will come on**.	
Step 2	Re-enter the **MASTER** code or type your own **MASTER** code then press. Enter (!See Warning Below!)	*111111*
Step 3	Type in your new 4 digit **USER** code, then press Enter.	*Your New Code* .....
Step 4	Enter the time in Seconds that you want the door to unlock for, and then press Enter. *(01-99= seconds)*	*05*
Step 5	Type in your second, 4 digit **USER** code (there are two codes for this type of keypad), then press Enter.	*Repeat Step 3*
Step 6	Again, enter the time in Seconds that you want the door to unlock for, and then press Enter. *(01-99= seconds)*	*05*
	Press Enter until the RED light goes out and a series of tones is heard.	

Typically, 5 seconds (05) in steps 4 & 6 is sufficient in time for the keypad to operate but if you need further guidance, please contact us for advice

If at any stage of the programming sequence you make a mistake, press Cancel, then Enter until the RED light goes out, then start from the beginning. Tip: Entering numbers slowly will reduce the risk of miss-programming the Keypad. Each press will give a tone – you may have to be close to the unit to ensure you can hear it.

NOTE: It is recommended that you do not alter the default MASTER code but if you do you MUST keep the information to-hand & safe. If a Service Call is required and is found to be as a result of a programming error, or work cannot be completed because of an unknown MASTER code, the Keypad may be reset to Factory defaults by the Engineer and you could be charged for the call